

VERTICAL INDICATOR POST



Vertical Indicator Post indicates if valve is in the open or shut position. The indicator post creates a way to operate a buried/inaccessible valve. Indicator post's adjustment range reaches 34.5" and can be easily adjusted on site. The wrench handle fits over a "U" bracket on the barrel, and may be fixed with a padlock to secure the operating wrench to the barrel. Ability to open left or right. UL Listed/FM Approved. Internally and externally red epoxy coated RAL3000 for corrosion protection.



Item #

700-275-00180

Field Adjustment:

- Remove the top section of the upper barrel of the indicator post
- Cut the stem to the required length and adjust the standpipe to match up to the GROUNDLINE
- Set the OPEN and SHUT targets for the appropriate valve size
- Re-attach the top section of the upper barrel of the indicator post

Material Specifications

No .	Component	Material
1	HexCapScrew	CarbonSteelASTMA307B
2	HexNut	CarbonSteelASTMA307B
3	CraneCoupling	DuctileIronASTMA536Gr. 65-45-12
4	CotterPin	StainlessSteelAISI304
5	BaseFlange	CastIronASTMA126ClassB
6	HexNut	CarbonSteelASTMA307B
7	HexCapScrew	CarbonSteelASTMA307B
8	Standpipe	CarbonSteelASTMA53
9	StemTSquare	CarbonSteelAISI1045
10	Body	CastIronASTMA126ClassB
11	LockingWrench	DuctileIronASTMA536Gr. 65-45-12 BronzeASTMB62C83600
12	TargetCarrierNut	StainlessSteelAISI304
13	HexCapScrew	CarbonSteelASTMA307B
14	HexNut	CarbonSteelASTMA307B
15	HexCapScrew	CarbonSteelASTMA307B
16	Target	CastAluminium
17	WindowGlass	Plexiglass
18	Gasket	PTFE
19	OperatingNut	BronzeASTMB62C83600 StainlessSteelAISI304
20	TopSection	CastIronASTMA126ClassB
21	SnapRing	StainlessSteelAISI1066
22	Plug	MalleableIron
23	SquareNut	CarbonSteelASTMA307B
24	HexCapScrew	CarbonSteelASTMA307B

